
Application
Class
Documents
DocumentCollection
Class
this
this
Document
Class
Windows
WindowCollection
Class
this
Window
Class
TabViews
TabViewCollection
Class
this xy
TabView
Class
IProxy
DrawingView
Class
TabView
IProxy
LayerView
Class
TabView
MasterDrawComponents
CustomHatchs
SelectionManager
UndoManager
ToolBars
ToolBarCollection
Class
this
ToolBar
Class
Items
ToolBarItemCollection
Class
this y
ToolBarItem
Class
IProxy
ToolBarSeparatorItem
Class
ToolBarItem
IProxy
ToolBarComboBoxItem
Class
ToolBarItem
IProxy
ToolBarButtonItem
Class
ToolBarItem
Drawings
DrawingCollection
Class
CommandManager
CommandManager
Class
Command
Class
ParameterGroups
CommandParameterGroupCollection
Class
this
CommandParameterGroup
Class
Items
ParameterItemCollection
Class
this
IProxy
ParameterItem
Class
IProxy
LineShape
Class
BasicShape
IProxy
IntegerParameterItem
Class
ParameterItem
IProxy
DoubleParameterItem
Class
ParameterItem
IProxy
ListParameterItem
Class
ParameterItem
IProxy
LengthParameterItem
Class
ParameterItem
IProxy
AngleParameterItem
Class
ParameterItem
IProxy


LayerTable
LayerTable
Class
RootLayer
Layer
Class
ChildLayers
LayerCollection
Class
Colors
ColorItemCollection
Class
this
ColorItem
Class
Linetypes
LinetypeItemCollection
Class
this
this
LinetypeItem
Class
Linewidths
LinewidthItemCollection
Class
this
LinewidthItem
Class
MasterDrawComponentCollection
Class
this
this
MasterDrawComponent
Class
Shapes
MasterDrawComponentShapeItemCollection
Class
CustomHatchCollection
Class
this
this
CustomHatch
Class
SelectionManager
Class
SelectedShapes
SelectedShapeCollection
Class
this
SelectedShape
Struct
UndoManager
Class
IProxy
BasicShapeSettings
PointMarkerSettings
TextSettings
BalloonSettings
LeadSettings
DimensionSettings
HatchSettings
this
this
Drawing
Class
Layouts
LayoutCollection
Class
this
this
Layout
Class
Shapes
ShapeCollection
Class
Part
Class
Drawing
Paper
Class
Drawing
PolylineShape
Class
BasicShape
CircleShape
Class
BasicShape
ArcShape
Class
BasicShape
EllipseShape
Class
BasicShape
EllipseArcShape
Class
BasicShape
InfiniteLineShape
Class
BasicShape
PointParameterItem
Class
ParameterItem
PointListParameterItem
Class
ParameterItem
ScaleParameterItem
Class
ParameterItem
ShapeParameterItem
Class
ParameterItem
ShapeGroupParameterItem
Class
ParameterItem


Geometry
Geometry
Class
Point2d
Struct
PrintSettings
PrintSettings
Class
IProxy
BasicShapeSettings
Class
ShapeSettings
IProxy
PointMarkerSettings
Class
ShapeSettings
IProxy
TextSettings
Class
ShapeSettings
IProxy
BalloonSettings
Class
ShapeSettings
IProxy
ShapeSettings
Class
Styles
ShapeSettingsStyleCollection
Class
this
this
ShapeSettingsStyle
Class
IProxy
LeadSettings
Class
ShapeSettings
IProxy
DimensionSettings
Class
ShapeSettings
IProxy
HatchSettings
Class
ShapeSettings
IProxy
Shape
Class
Attributes
ShapeAttributeCo···
Class
this
this
ShapeAttribute
Class
IProxy
BasicShape
Class
Shape
IProxy
PointMarkerShape
Class
Shape
IProxy
TextShape
Class
Shape
IProxy
BalloonShape
Class
Shape
IProxy
LeadShape
Class
Shape
IProxy
DimensionShape
Class
Shape
IProxy
HalfInfiniteLineShape
Class
BasicShape
IProxy
BSplineCurveShape
Class
BasicShape
IProxy
LinearDimensionShape
Class
DimensionShape
IProxy
RadiusDimensionShape
Class
DimensionShape
IProxy
DiameterDimensionShape
Class
DimensionShape
IProxy
ParallelDimensionShape
Class
LinearDimensionShape


IProxy
HatchShape
Class
Shape
IProxy
ImageShape
Class
Shape
IProxy
OleObjectShape
Class
Shape
IProxy
DrawComponentShape
Class
Shape
IProxy
DrawGroupShape
Class
Shape
Shapes
DrawGroupShapeItemCollection
Class
IProxy
AngularDimensionShape
Class
DimensionShape
IProxy
ArcDimensionShape
Class
DimensionShape
IProxy
ToleranceShape
Class
DimensionShape